

PRESSURE/TORQUE CONVERSION CHART FOR RSL 14

Pressure PSI	ft-lbs	N-m
1000	961	1303
1200	1188	1611
1400	1414	1917
1600	1641	2225
1800	1867	2531
2000	2094	2839
2200	2320	3145
2400	2547	3453
2600	2773	3760
2800	3000	4067
3000	3226	4374
3200	3453	4682
3400	3679	4988
3600	3906	5296
3800	4132	5602
4000	4359	5910
4200	4585	6216
4400	4812	6524
4600	5038	6831
4800	5265	7138
5000	5491	7445
5200	5718	7752
5400	5944	8059
5600	6171	8367
5800	6397	8673
6000	6624	8981
6200	6850	9287
6400	7077	9595
6600	7303	9901
6800	7530	10209
7000	7756	10516
7200	7983	10823
7400	8209	11130
7600	8436	11438
7800	8662	11744
8000	8889	12052
8200	9115	12358
8400	9342	12666
8600	9568	12972
8800	9795	13280
9000	10021	13586
9200	10248	13894
9400	10474	14201
9600	10701	14508
9800	10927	14815
10000	11154	15123